

**Cone Die Holder** is used for external threading with Cone Dies. Cone die holders are also known as Spring Die Holders, Acorn Die Holders, Taper Nose Die Holders and Cap Adjusting Die Holders.



#### CONE DIE HOLDER

HOLDER SIZE	SHANK DIA.	HOLDS CONE DIE O.D.	CONE DIA CAPACITY	MAXIMUM LENGTH OF THREADS
#1	3/4	5/8 (#1)	#0 - 1/4	1-1/2
#2	3/4	7/8 (#2)	#6 - 3/8	2-3/4
#2	1	7/8 (#2)	#6 - 3/8	3
#3	3/4	1 -1/4 (#3)	3/8 - 5/8	2-3/4
#3	1	1-1/4 (#3)	3/8 - 5/8	3-3/4
#4	1	1-3/4 (#4)	5/8 - 1	2-1/2
#5	2	2-5/32 (#5)	1-1/8 - 1-1/2	3-3/4